

Note: Tilt and sliding door bottom frame shall be sitting directly on the floor as shown. In addition to 10mm tolerance, thickness of floor should be added to the structural height for the door as well.

For carpet or timber floor, the door can be made with jambliner at the bottom. Door sill can be fixed through jamliners.

If no jambliner at the bottom, door sill can be fixed through the PVC-U frame or using fixing bracket attached at the bottom of the frame. Discuss with Homerit for options.

